

How to upgrade TP-LINK Switch

Notice:


- **Please verify the hardware version of your device for the firmware version. Wrong firmware upgrading may damage your device and void the warranty.**





	Published Date	2013/7/31
	Language	English
	File Size	3.98 MB
	Operating System	Win2000/XP/2003/Vista/7/8/Mac/Linux
	Modifications and Bug Fixes	1. Added some new functions including LACP, Loopback Detection, Voice VLAN, ACL, SSL, SSH and so on. 2. Fixed some minor bugs.
	Notes	For TL-SG2424 V1

- **After you downloaded the firmware from TP-LINK website, please use decompression software such as WinZIP or WinRAR to extract the firmware file to a folder;**
- **Do NOT turn off the power or cut down the Ethernet cable during upgrade process;**
- **Please write down all current settings as a backup and enter them manually after upgrading.**
- **Internet Explorer(IE) is recommended to upgrade the firmware.**

Step 1 Connect the PC to the switch, set the IP address of your PC to 192.168.0.2-254 (eg.192.168.0.2), set subnet mask to 255.255.255.0




Step 2 Log into the switch by typing <http://192.168.0.1> in the address bar of the web browser (such as Internet Explorer, Firefox). The **UserName** and **Password** are both **admin** unless you have changed it before.



Step 3 Click **System** ->**System Tools** ->**Firmware Upgrade**, click the **Browse** button to choose the firmware you already extracted in the folder.(For

TL-SG1016DE and TL-SG1024DE, you will need to click **Ready** and have a restart before the upgrade)

Step 4 Click the **Upgrade** button. The device will reboot automatically after the upgrading has been finished. Please wait about 1 minutes.



Firmware Upgrade

You will get the new function after upgrading the firmware.

Firmware File:

Browse...

Upgrade

Step 4 Click **System ->System Info ->System Summary**, verify that the switch's firmware has been upgraded.

Firmware Version: 2.7.1 Build 20120330 Rel.63421